


CCK-FRONT



1	Step driver 521 (LEFT -X AXIS)	6	Step driver 424/524 (RIGHT-Z AXIS)	11	HUB
2	Step driver 521 (LEFT-Y AXIS)	7	Step driver 424 /524(POT TABLE)	12	NMC 402/3S CONTROLLER
3	Step driver 521 (RIGHT-X AXIS)	8	POWER SUPPLY +24V	13	SOLENOID BOARD (WATER,AUX)
4	Step driver 521 (RIGHT -Y AXIS)	9	POWER SUPPLY +24V,+5V	14	
5	Step driver 424 /524(LEFT-Z AXIS)	10	I/O CARD	15	